

## Installation Notes

The order of operations for installation of the 2 QT deep sump (after installing the pickup tube and extension) requires the steel baffle plate to be installed first (using the provided Loctite 5900), then the provided gasket (using no sealant), then the 1" pan spacer, then the oil pan itself (using the Loctite 5900).







