



1 -

Undo the 13mm nuts from both sides.



2 - Do not tap the threaded stud out. Turn it by hand anti clockwise until completely removed



3 – Unit disassembled



4 – Insert shifter lever favoring right hand side and inser threaded shaft. Turn clockwise until it stops



5 – Tighten nuts and proceed with gearshift installation