

DESIGN 911
Centre for Porsche

Installation Instructions

B-Post retrim Porsche 911 – all models



1. Remove the weatherstrip in the door opening where the B-posts should attach.
2. Remove you old B-post covers.
3. Degrease the door weatherstrip gutter where the B-posts should attach.
4. Degrease the area behind the metal flange and at the bottom where the B-posts should attach.
5. Evaluate whether you need to apply correction foam to nicely fill out (leave the old Compripol foam element).
6. In case you decide to use the correction foam only glue to the edges to ensure the cell structure stays intact.
7. With the foam in position, apply glue to the door weatherstrip gutter
8. 8. Start by attaching the B-posts to the door gutter and on the corresponding part of the vinyl (do not overdo on the vynil).
9. Position the bottom and apply slight tension as you work downward.
- 10.To ensure a good bond do not hesitate to push in some old newspaper with your fingers (where normally the weatherstrip sits).
- 11.Apply glue to behind the metal flange and on the corresponding part of the vinyl (do not overdo on the vynil).
- 12.Now position the B-posts behind the metal flange and apply slight tension as you work around.
- 13.To ensure a good bond do not hesitate to push in some old newspaper with your fingers (where normally the weatherstrip sits).
- 14.Follow the same process to glue the bottom.

We are continuously striving to improve our offering. If you have suggestions to improve our product or these installation instructions, please send them to sales@design911.com. Thank you.