

## R-9036 REAR TOW HOOK

944 85 ½ and up

Step 1:



Locate the three nuts located on the inside of the rear quarter panel.

Step 2:



Remove nuts. Install bracket as shown. Note: You may want to apply some sealer around the studs to prevent water leaking into the trunk. Install and tighten nuts.

Performance driving events are by nature potentially hazardous to your health. Brey-Krause Mfg. Co. Inc. shall not be liable for injury, consequential, or other types of damages resulting from the use or misuse of our products. Proper installation of these parts is critical and should only be done by a professional shop.